

Product overview

Overview

| Devices | | Standards | Used in | | |
|---|--|--|--|-----------------------|----------|
| | | | Non-residential buildings | Residential buildings | Industry |
| Multimeters |  | Display of 23 electrical measured values for switchgear assemblies, infeed or outgoing feeders. Easy commissioning due to fault detection if connected incorrectly. | IEC 60051-2, EN 60051-2 IEC 61010-1, EN 61010-1 (VDE 0411 T 1) | ✓ -- | ✓ |
| Multicounters |  | Display of 35 electrical measured values and consumption values in switchgear assemblies, infeed or outgoing feeders. Easy commissioning due to fault detection if connected incorrectly. Transmission of measured values over Profibus DP, Modbus RTU or LAN. | IEC 60051-2, EN 60051-2 IEC 61010-1, EN 61010-1 (VDE 0411 T 1) IEC 62053-21, EN 62053-21 (VDE 0418 T 3-21) | ✓ -- | ✓ |
| LAN couplers |  | Up-to-date consumption data of the multicounter and E-counter available worldwide over LAN data communication. Microsoft Excel operator interface. Signaling of limit violations with time stamp. | IEEE 802 | ✓ -- | ✓ |
| E-counters |  | Measurement of consumption data and plant capacity utilization in three-phase systems of system components, offices or holiday apartments. Transmission of measured values over LAN using LAN couplers. | IEC 61010-1, EN 61010-1 (VDE 0411 T 1) IEC 62053-11, EN 62053-11 (VDE 0418 T 3-11) IEC 62053-21, EN 62053-21 (VDE 0418 T 3-21) | ✓ ✓ | ✓ |
| E-counters <i>instabus KNX EIB</i> |  | Measurement of consumption data and plant capacity utilization in three-phase systems of system components, offices or holiday apartments. Transmission of measured values over <u>instabus KNX EIB</u> interface | IEC 61036 EN 61036 (VDE 0418 T 7) | ✓ -- | ✓ |
| Current transformers |  | Straight-through transformers for installation in distribution boards and non-contact measuring of primary currents. Ideal for combining with switch disconnectors, multimeters, multicounters and E-counters. | IEC 60044-1, EN 60044-1 (VDE 0414 T 44-1) | ✓ -- | ✓ |
| Measuring selector switches |  | For switching over the phases for voltmeters and ammeters | | ✓ -- | ✓ |