

## SBP incremental encoder board

The incremental encoder SBP (Sensor Board Pulse) enables an incremental encoder or frequency generator setpoint to be connected to converters and inverters.

When ordering the board, the order number of the compact and chassis units is to be supplemented with "-Z" and the corresponding code for direct mounting in the appropriate mounting slot.

Factory mounting, plugged into slot	Supplementary order code	Retrofit kit for retrofitting (supplied loose) Order No.	Spare part (board without connectors and instruction manual) Order No.
-------------------------------------	--------------------------	--	--

SBP		Incremental encoder board	
		6SX7010-0FA00	6SE7090-0XX84-0FA0
A	<b>C11</b>		
C	<b>C13</b>		
D	<b>C14</b>		
E	<b>C15</b>		
F	<b>C16</b>		
G	<b>C17</b>		
A	<b>C11</b>		
B	<b>C12</b>		

Compact and chassis units

Compact PLUS units