

LZS:PT relay couplers

Complete units, 11- and 14-pole, PT series

LZS:PT3A5

LZS:PT5A5




Standard plug-in base with screw terminals

LZS:PT5B5

Plug-in base with logical isolation and screw terminals

LZS:PT5D5

Plug-in base with logical isolation and spring-loaded terminals



LZX industrial relays, 8-, 11-, and 14-pole, PT series

LZX:PT270, 8-pole




2 CO

LZX:PT370, 11-pole

3 CO

LZX:PT520, LZX:PT570, LZX:PT580, 14-pole

4 CO



Plug-in bases for PT series

LZS:PT78740




With screw terminals

LZS:PT78742

with logical isolation and screw terminals

LZS:PT7874P

with logical isolation and spring-loaded terminals



Controls – Contactors and Contactor Assemblies

Project planning aids

LZS:RT relay couplers

Complete units, 8-pole, 5 mm pinning, RT series

**LZS:RT3A4;
LZS:RT4A4**




Standard plug-in base with screw terminals

**LZS:RT3B4;
LZS:RT4B4**


Plug-in base with logical isolation and screw terminals

**LZS:RT3D4;
LZS:RT4D4**

Plug-in base with logical isolation and spring-loaded terminals



LZX:RT3; LZX:RT4 print relays



Plug-in bases for RT series

LZS:RT78725




With screw terminals

LZS:RT78726

with logical isolation and screw terminals

LZS:RT7872P

with logical isolation and spring-loaded terminals




Controls – Contactors and Contactor Assemblies

Project planning aids

LZX:MT relay couplers

Industrial relays, 11-pole, MT series

LZX:MT32



LZS:MT78750 plug-in bases

For industrial relays

